




AMG2783D-1-DR-SF Instruction Manual

Single Channel Video Insert Unit with Bi-directional Data Dual Redundant on a single fibre ring



AMG2783D-1-DR-SF is a single channel video insert unit designed to transmit a video signal on to a single dual redundant optical fibre ring. It also provides a RS485/RS422 bi-directional data channel. The **AMG2783D-1-DR-SF** unit is supplied mounted in a basic subrack as shown below.




The **AMG2783D-1-DR-SF** is designed to operate with the **AMG2784-DR-SF** eight channel video and data receiver. Each receiver will 'drop off' up to eight video channels which are being transmitted around the single fibre ring.

Introduction

Unit Functional Schematic

The **AMG2783D-1 DR-SF** transmits and receives optical signals from both a primary and secondary optical channels. These optical channels are transmitted on the same optical fibre indifferent directions, operating at different wavelengths. The primary channel operates on 1550nm and the secondary channel on 1310nm.

The **AMG2783D-1-DR-SF** receives and drops off a data signal transmitted from an **AMG2784R-DR-SF** receiver. It then inserts a video and data signal onto the outgoing optical signal. The video signal is inserted on 1 of 8 channels available on the optical signal. The insert channel number is set by SW1 inside the unit (see below). If the video channel is set to a channel that already has a video signal on it, this unit will over-write this in-coming video signal.



In normal operation where connection of both the previous unit and the subsequent unit are OK, the video and data signal is transmitted on the primary output and the data received from the primary input. The secondary optical input is independent and is regenerated on the secondary output.

If the primary input signal is not present, the unit will shut down the secondary output to inform the previous unit that the signal route is not OK. The previous unit will then send out the video and data signals on its secondary output in the opposite direction. This signal will be repeated around the ring to get back to this **AMG2783D-1-DR-SF** on the secondary route. As the primary input is not present on this unit, the data signal will now be taken from the secondary optical input. Thus maintaining integrity of the data transmission.

If the secondary input signal is not present, the unit will assume that the route to the next unit is not OK and send out the video and data signal on the secondary optical output. This video and data will be transmitted to the next unit around the ring in the opposite direction on the secondary route.

Connections

Video Input Connection

Connector 75 ohm BNC Socket.
Input Impedance 75 ohm terminated.
Input Level 1 volt p-p nominal
Frequency Response 10Hz to 5.75MHz min.
See below for **video input channel configuration**

Optical Connections

PRIMARY OPTO OUT

Connector FC/PC
Primary Optical Launch Power -6dBm
Wavelength 1550nm

Secondary Optical Sensitivity -21dBm
Wavelength 1310nm

PRIMARY OPTO IN


Connector FC/PC
Primary Optical Sensitivity -21dBm
Wavelength 1550nm

Secondary Optical Launch Power -6dBm
Wavelength 1310nm

Power Connection

Connectorscrew terminal connector
Power requirement 12 volts to 16 volt DC @ 800mA

Connections..... See schematic
+ve in right hand terminal




Data Connections


Data Connector 5 way removable spring terminal connector (2.5mm spacing)
Manufacturers Part No. Phoenix/Combicom FK-MC-0.5/5-ST-2.5
AMG Part No G15098-00

Data Channels 1


Connections RS422 4 wire See schematic



Connections RS485 4 wire See schematic



Connections RS232.....See schematic



Protocol..... RS232
SW1 switch position 9 on, switch position 10 on
SW2 all off

RS485 2wire
SW1 switch position 9 off, switch position 10 off
SW2 see below

RS422 4 wire Bus'ed or point to point
SW1 switch position 9 off, switch position 10 off
SW2 see below

See below for **Configuration of the RS485 / RS422 data channel** and description of tristate operation

Indicators

Power.....	Green	– unit powered
	Off	– no power applied to unit
Primary Opto Sync TX	Green	- Primary optical channel transmitting
	Off	- Primary optical channel not transmitting
Primary Opto Sync RX	Green	- Primary optical channel receiving
	Off	- Primary optical channel not receiving
Secondary Opto Sync TX	Green	- Secondary optical channel transmitting
	Off	- Secondary optical channel not transmitting
Secondary Opto Sync RX	Green	- Secondary optical channel receiving
	Off	- Secondary optical channel not receiving
Video Present CH1	Green	– video signal present on video CH1 input BNC
	Off	– no video present on video CH1 input BNC
Data Present TX	Green	– logic one present on the corresponding data
	input	
	Red	– logic zero present on the corresponding data
	input	
	Off	– tri-state present on the corresponding data
	input	
This represents the data signals being transmitted on the optical fibre		
Data Present RX	Green	– logic one present on the corresponding data
	output	
	Red	– logic zero present on the corresponding data
	output	
	Off	– tri-state present on the corresponding data
	output	

This represents the data signals being received on the optical fibre

Physical Information

Dimensions

Height 3U
Width..... 19" rackmount
Depth 280mm
Weight..... 1000grams

Mounting Details

The unit is designed to be mounted in a 19" rack

Configuration of the Data Channel

SW1 and SW2 determine the protocol of the data channel. This can be RS232, RS485 or RS422.
(See below for **removal from the case** and access to SW1 and SW2)

Mode 1 – RS485 two wire half duplex transmission.

Mode 2 – RS422 four wire full duplex transmission.

In this mode the RS422 output will transmit a tristate condition as well as logic high and logic low for systems which require bus-ing of the RS422 four-wire connection.

MODE	Configuration Details	SW2 position 1	SW2 position 2	SW2 position 3	SW2 position 4	SW1 position 9	SW1 position 10
1	RS-485 2 wire BUS systems	OFF	ON	ON	ON	OFF	OFF
2	RS-422 4 wire Point-to-Point - and RS-422 BUS system	OFF	OFF	OFF	OFF	OFF	OFF

Note: - when used with a 2788 with the individual channel A data channels routed to a separate data card (not on-board data at the RX), RS485 operation and the tri-state RS422 output is not available. RS485 operation can only be selected if on-board data is selected at the RX.

The data input for both the RS485 and the RS422 modes detects a tri-state input condition by monitoring the differential voltage level across the input. A differential level below 500mV positive or negative will be detected as a tristate condition. A level above 500mV positive or negative will be detected as a logic 1 or logic zero respectively. **It is important therefore to terminate the RS485 bus or the RS422 input bus using 120ohms if a pre-bias is present on the RS485 or RS422 bus.** A large number of third party equipment manufacturers apply a pre-bias on their RS485 bus. This pre-bias is applied by pulling one arm of the RS485 bus high (+5 volts) and the other arm low (0 volts) using high value resistors within the third party equipment. In order to ensure that the AMG2700 equipment detects a tri-state condition, then these resistors should have a value above 1kohm.

Mode 3 – RS232 full duplex transmission.

MODE	Configuration Details	SW2 position 1	SW2 position 2	SW2 position 3	SW2 position 4	SW1 position 9	SW1 position 10
3	RS-232 Point to Point	OFF	OFF	OFF	OFF	ON	ON

Note: - the data channel is set at Mode 1 – RS485 operation at the factory unless otherwise requested.

It is normal to set each AMG2700 insert unit to a different channel number. If a number is used twice the second unit connected 'down stream' on the primary optical route will 'over-write' the first unit and the video signal will be lost.

The channel number is only required to be set on SW1 on the primary channel TX card. Positions 1 to 3 on SW1 on the secondary channel TX card do not effect the operation of the equipment.

Video input channel configuration

The video present on the video input can be inserted on one of eight video channels transmitted on the optical fibre. The input channel number is set by SW1 on the primary channel TX board. (See below for **removal of the PCB** and access to SW1)

The channel number is set by the SW1 switch positions 1 to 3 – see below.

Video Input Channel Number	SW1 position 1	SW1 position 2	SW1 position 3
1	OFF	OFF	OFF
2	ON	OFF	OFF
3	OFF	ON	OFF
4	ON	ON	OFF
5	OFF	OFF	ON
6	ON	OFF	ON
7	OFF	ON	ON
8	ON	ON	ON

It is normal to set each AMG2700 insert unit to a different channel number. If a number is used twice the second unit connected 'down stream' on the primary optical route will 'over-write' the first unit and the video signal will be lost.

The channel number is only required to be set on SW1 on the primary channel TX card. Positions 1 to 3 on SW1 on the secondary channel TX card do not effect the operation of the equipment.

SW1 Switch Settings

Only switch positions 1 to 3 should be set by the user, all other switch settings are set at the factory as follows:

Primary Channel TX Card (Single Channel Video TX Card)

Switch Position	Description	Setting
1	Video channel configuration	See above
2	Video channel configuration	See above
3	Video channel configuration	See above
4	Primary / Secondary Board Setting	ON
5	Dual Redundant / Not dual redundant	ON
6	Not Used	OFF
7	Not Used	OFF
8	On board data / Separate data card	ON
9	RS232 Select	OFF
10	RS232 Select	OFF

Secondary Channel TX Card (Zero Channel Video TX Card)

Switch Position	Description	Setting
1	Not Used	OFF
2	Not Used	OFF
3	Not Used	OFF
4	Primary / Secondary Board Setting	OFF
5	Dual Redundant / Not dual redundant	ON
6	Not Used	OFF
7	Not Used	OFF
8	Not Used	OFF
9	Not Used	OFF
10	Not Used	OFF

Removal From the Case

Note: - The 2700 PCB's are static sensitive. Handle with proper care and use normal electrostatic discharge (ESD) procedures. Use properly grounded protection (for example, wrist stamps) when handling the PCB. The switch positions can be accessed without pulling out the boards from the case fully. It is recommended that the boards are slid out just sufficient to access the switches (~40mm) in order to reduce the possibility of damage to the optical fibres and electrical circuits.

In order to remove the case (to access SW1 and SW2)

- 1.1. Loosen and remove the four screws on the top and bottom of the unit's rear panel.
- 1.2. Slide the PCB assembly connected to the rear panel back from the case.
- 1.3. Ensure that the optical fibre is not trapped.
- 1.4. The Primary Channel TX card is the PCB which has the video input BNC attached through the rear panel labelled CH1.

SW1 and SW2 can be found on the bottom right hand corner of each board and are labelled, close to the rear panel. The switch position are labelled on the switch, switch position 1 is always the furthest from the edge of the PCB.

When re-inserting the main PCB into the housing take care not to trap the optical fibre or the board interconnection cables.

Fasten the rear panel with the screws.

Safety

The 2700 series of products uses a Class 1 laser system in accordance with EN 60825-2:2000 and as such the optical power emitted from the optical connector is regarded as eye safe under all operating conditions.

However it is always advisable to follow good practice when working with optical fibre systems. This includes:

- Do not stare with unprotected eyes or with any unapproved collimating device at fibre ends or connector faces, or point them at other people.
- Use only approved filtered or attenuating viewing aids

For other safety issues and advice on good practice associated with the optical fibres systems see EN 60825-2:2000 or your local safety officer.

There are no user serviceable parts within the AMG2700 products.

In case of problem or failure contact your local support centre or AMG Systems Ltd, Technical Support Department on tel. +44 (0) 1767 600777.

See unit data sheet for full specification.