/ DEVICE RESET PROCEDURE

① Remove all connections from the RJ45 & SFP ports.

② Insert an Ethernet patch cable between ports 1 & 2 on the switch.

③ Power cycle the switch with the loop-back cable in place and the switch will reboot and apply the factory default configuration settings.

④ Remove the loop-back cable and re-connect the existing Ethernet and optical patch cables.

## / CONNECTING TO THE SWITCH

Web GUI

Default IP Address:	192.168.1.101
Username:	admin
Password:	admin

Console CLI

RJ45 to DB9 Cable	115200,8,N,1

To access the full software user guide for this product please visit the product page using the QR code opposite or the direct link below:

amg-support.com/AMG510-24G-4XS-RP

AMG510-24G-4XS-RP
10Gb Layer 2+ Ethernet Switch

## Installation Manual - Hardware

AMG510

**AMG**
amgsystems.com

/ AMG510-24G-4XS-RP MODEL

AMG510-24G-4XS-RP

| Model	Description
AMG510-24G-4XS-RP	24 × 10/100/1000T(x) Ports + 4 × 1/2.5/10Gb SFP+ Ports Dual Redundant Mains Power Supplies

/ RACK MOUNT INSTALLATION

① Attach the rack ears using the screws provided as shown.

② Secure the unit into the 19inch rack using four cage nuts (not supplied).

/ DESKTOP INSTALLATION

① Attach the rubber feet supplied as shown to prevent scratches.

/ PORTS & LED INDICATORS

LED's

24x 10/100/1000T(x) Ports

4x 1/2.5/10Gb SFP+ Ports

Console Port

Product Label

Cooling Vent

Dual Field Replaceable Power Supply Modules

Power Fail Alarm Reset Switch

LED	Colour	Description
POWER	Yellow	Power On
LINK/ACT	Green	Link present (flashes with data traffic activity)
1G	Green	Port is connected at 1Gb speed