


# AMG5742 Instruction Manual

# Quad System with 4x Independent Channels each of :

# [Single Channel Video Receive Unit for a Singlemode Fibre Link]



The **AMG5742** is a **QUAD** standalone system which provides four independent channels, each designed to receive one video signal over one Singlemode optical fibre. i.e. a total of four optical fibres.

The AMG5742 is designed to be powered using an AMG2001 standalone power supply.

The **AMG5742** is designed to operate with four **AMG5711** single channel video transmit units in a point to point configuration.

# **Contents**

Introduction	3
Unit Functional SchematicOptical Connection	
Connections	4
Video Output Connections Optical Connections Power Connection	4
Front Panel Indicators	4
Power LED	4
Physical Information	5
Dimensions	5
Safety	5
Maintenance and Repair	5


#### Introduction

#### **Unit Functional Schematic**

The **AMG5742** provides four independent, receive channels.


Each channel receives one video signal from up to four independent **AMG5711** transmit units.

The schematic diagram shows one of the four available channels of the **AMG5742** 



#### **Optical Connection**

The **AMG5742** connections are illustrated in the following example which shows four **AMG5711** single channel transmit units together with an **AMG5742** configured as a quad channel point to point system.



#### **Connections**

#### **Video Output Connections**

#### **Optical Connections**

Minimum Optical Dynamic Range ......20dB.

#### **Power Connection**

#### Front Panel Indicators

#### **Power LED**

Power / Video / Opto......Green - Video present & opto sync.

R/G - Opto sync. but no video present.

Red - No opto sync.

Off - No power applied to unit.

### Physical Information

#### **Dimensions**

Height	112mm
Width	
Depth	35mm `
Weight	

#### **Mounting Details**

The AMG unit is supplied with a clip-on mounting bracket which should be attached to a panel or wall using 2 off 4.0mm screws, see diagram on page 1 for dimensions. The unit is clipped into the mounting bracket, and is then held firmly in position.

#### Removal / replacement from / to the Case

Note: - The AMG unit PCB is static sensitive. Handle with proper care and use normal electrostatic discharge (ESD) procedures. Use properly grounded protection (for example, wrist straps) when handling the PCB out of the case.

To remove the PCB from the case for example to access a Low Speed Data mode switch, remove the 2 fixing screws on the rear panel and slide the PCB sufficiently out of the case to enable access to the switch.

To replace the PCB into the case, slide the PCB gently into the case, if necessary aligning the board with the appropriate slots.

### Safety

AMG Optical Fibre Products use Class 1 laser systems in accordance with EN 60825-2:2000.

It is always advisable to follow good practice when working with optical fibre systems. This includes:

- Do not stare with unprotected eyes or with any unapproved collimating device at fibre ends or connector faces, or point them at other people.
- Use only approved filtered or attenuating viewing aids

For other safety issues and advice on good practice associated with optical fibre systems, please see EN 60825-2:2000 or your local safety officer.

## Maintenance and Repair

There are no user serviceable parts within AMG products. See unit data sheet for full specification.

In case of problem or failure, please call your local support centre or contact: **AMG Systems Ltd.** at 3 The Omega Centre, Stratton Business Park, Biggleswade, Beds., SG18 8QB, UK.

Phone +44 (0) 1767 600 777 Technical Support +44 (0) 1767 604 491

Email techsupport@amgsystems.com

